

Index

A

- ACC card
 - LEDs 6
 - location in Application Module 8
- accessing CCR log file 301
- ACD *see* Automatic Call Distribution (ACD)
- ACD DN *see* Automatic Call Distribution Directory Number (ACD DN)
- adding a printer 64
- admin command 20
- advanced diagnostic tests 167
- advanced maintenance 16
- AEM 467
- AM *see* Application Module (AM)
- AM link (link 0) not established
 - diagnosing 208
- AML 467
 - administration commands 16
 - definition 467
- applconfig command 20
- applexit command 21
- application
 - testing for 187
- application message
 - summary 237
 - SysLog file 265
 - SysLog file summary 265
- Application Module (AM) 467
 - error messages 235
 - front view 8
 - hardware components 4
 - overview 1
 - rear view 9
- Application Module command
 - admin 20
 - applconfig 20
 - applexit 21
 - applstart 21
 - backconfig 22
 - backdata 27
 - backfiles 31
 - bootconfig 34
 - ccrexist 35
 - ccrstart 37
 - ccrtraffic 37
 - ccrusr 43
 - chgpasswd 44
 - conshare 45
 - diskuse 47
 - editvoice 47
 - exit 48
 - filedelete 49
 - fileverif 50
 - help 51
 - install 52
 - langconfig 55
 - midnight 36
 - mlexit 56
 - mlstart 56
 - mlusr 56
 - portconfig 57
 - powerdown 59
 - printconfig 63
 - quit 67
 - resetmodem 67
 - restart 68
 - rootpasswd 69
 - rstdata 70
 - rstfiles 73
 - scriptinfo 74
 - showid 75
 - startNSE 76
 - stopNSE 77
 - summary 18
 - tapeinfo 78
 - version 79
 - view 82
 - viewlog 84
- Application Module Link (AML) *see* AML

- Application Module utilities
 - ccrusr 15
 - maint 15
 - mlusr 15
 - trmcnfg 16
- application registration fails
 - Meridian Link application malfunction 225
- application tape
 - loading onto hard disk 439
- applstart command 21
- association 74
 - removing a stale mlusr association 298
 - stale 298
- association services commands 118
- Asynchronous Communication Controller (ACC) card LEDs 6
- attendant 345, 468
- Automatic Call Distribution (ACD) 468
- Automatic Call Distribution Directory Number (ACD DN) 468

B

- backconfig command 22
- backdata command 27
- backfiles command 31
- backing up
 - configuration files and data files 452
 - restoring configuration files and data files 454
- bad-event message 284
- Base Operating System (BOS) *see* BOS
- bootconfig command 34
- BOS 468
 - definition 468
 - installation (phase 1) (IPE Module or MVME167 card) 419
 - installation (phase 1) (MVME147 card) 402
 - installation (phase 2) (IPE Module or MVME167 card) 424
 - installation (phase 2) (MVME147 card) 405

- installation (phases 3 and 4) (IPE Module or MVME167 card) 427
- installation (phases 3 and 4) (MVME147 card) 408
- loading (IPE Module or MVME167 card) 410
- loading (MVME147 card) 393

C

- cable connection
 - MVME705B card 390
- call processing functions fail
 - diagnosing faults 228
- card
 - diagnosing fault 165
 - reseating 167
- card fault suspected (Application Module)
 - diagnostic procedure 165
 - diagnostic procedure flowchart 168
- card fault suspected (IPE Module)
 - diagnostic procedure 165
 - diagnostic procedure flowchart 174
- cassette tape
 - inserting 24, 28, 32
 - write-protection disabled 23, 27, 31
- caution 4, 10, 12, 22, 27, 31, 102, 369, 371, 376, 393, 401, 418, 439, 442, 448, 463
- CCR
 - Line Printer Configuration Utility 63
 - log file commands 302
 - log file message description 304
 - overview 1, 2
 - Traffic and Statistics Reporting Utility 37
 - viewing log file messages 301
- CCR Module overview 1
- ccrexist command 35
- ccrstart command 37
- ccrtraffic command 37
- ccrusr
 - description 15
 - login 15
 - login failure 205

- ccrusr command 43
- CDN see Control Directory Number (CDN)
- central office (CO) 468
- change link command 102
- change linkctl command 95
- changing port characteristics 58
- checking
 - ACD configuration 233
 - application and DN registration 232
 - application registration 229
 - Meridian 1 configuration 233
 - Meridian Link Module software services 229
 - telephone configuration 230
 - USM configuration 233
- checklist
 - quick reference fault isolation 155
- chgpasswd command 44
- circuit breaker
 - MPDU 10
- clear filter messages command 126
- clear message for monitoring command 133
- clear messages for statistics command 122
- clear record command 130
- CO see central office (CO)
- command
 - admin 20
 - applconfig 20
 - appexit 21
 - Application Module 17
 - applstart 21
 - backconfig 22
 - backdata 27
 - backfiles 31
 - bootconfig 34
 - CCR log file 302
 - ccrexist 35
 - ccrstart 37
 - ccrtraffic 37
 - ccrusr 43
 - change link 102
 - change linkctl 95
 - chgpasswd 44
 - clear filter messages 126
 - clear message for monitoring 133
 - clear messages for statistics 122
 - clear record 130
 - conshare 45
 - continuity test 143
 - disable filter 125
 - disable link 91
 - disable message statistics collection 122
 - disable monitor 133
 - disable recording 129
 - disable traffic 136
 - diskuse 47
 - display link 100
 - display linkctl 94
 - editvoice 47
 - enable filter 125
 - enable link 91
 - enable message statistics collection 121
 - enable monitor 132
 - enable record 129
 - enable traffic 135
 - exit 48, 150
 - filedelete 49
 - fileverif 50
 - get associations 118
 - get directory 119
 - get filter status 126
 - get links 92
 - get message statistics 123
 - get monitor status 134
 - get record 130
 - get resource 120
 - get traffic 136
 - help 51, 150
 - install 52
 - langconfig 55
 - link maintenance 85
 - link statistics 114
 - loopback test 144

- message statistics 121
 - midnight 36
 - mlexit 56
 - mlstart 56
 - mlusr 56
 - mlusr commands fail 289
 - portconfig 57
 - powerdown 59
 - printconfig 63
 - quit 67, 150
 - read link 113
 - read linkctl 98
 - resetmodem 67
 - restart 68
 - rootpasswd 69
 - rstdata 70
 - rstfiles 73
 - save link 112
 - save linkctl 99
 - scriptinfo 74
 - set filter 124
 - set monitor 131
 - set record 128
 - showid 75
 - startNSE 76
 - status link 92
 - stopNSE 77
 - summary of Application Module commands 18
 - summary of link maintenance commands 87
 - tapeinfo 78
 - trace link 139
 - trace main 139
 - untrace link 139
 - untrace main 139
 - version 79, 153
 - view 82, 148
 - viewlog 84, 149
 - Command and Status Link (CSL) 468
 - components
 - hardware (Application Module) 4
 - hardware (IPE Module) 11
 - configuration
 - link 0 (LAPB) 100
 - link 1 (X.25) 100, 101
 - link 2 (ASYNC) 101
 - MVME705B card serial port 391
 - MVME712A card 387
 - MVME712AM card 388
 - MVME712M card 389
 - configuration file
 - restoring from backup 454
 - configuration files and data files
 - backing up changes 452
 - configuration parameters 217
 - configuring
 - MVME147 card 371
 - MVME167 card 376
 - traffic report 38
 - connector
 - I/O 13
 - conshare command 45
 - console
 - diagnosing fault 176
 - console fault suspected
 - diagnostic procedure flowchart 176
 - continuity test command 143
 - Control Directory Number (CDN) 469
 - control file
 - changing 95
 - displaying 98
 - displaying all 94
 - saving 99
 - counting messages 135
 - creating voice prompts 47
 - CSL see Command and Status Link (CSL)
 - Customer Controlled Routing (CCR) see CCR
- ## D
- data files
 - restoring from backup 454
 - debugging tools

- message failure 231
 - deleting
 - a file 49
 - printer 64
 - printer job 66
 - diagnosing
 - application does not receive expected messages 231
 - application registration failure 225
 - call processing functions fail 228
 - faults 155
 - link 0 failure 208
 - link 1 failure 215, 223
 - link 2 failure 224
 - Meridian Link application failure 225
 - diagnostic procedure
 - advanced 167
 - Application Module card fault suspected flowchart 168
 - Application Module power fault suspected flowchart 156
 - application terminal problem 188
 - card fault suspected 165
 - dial-up problem flowchart 185
 - disk/tape drive unit faults 204
 - IPE Module card fault suspected flowchart 174
 - IPE Module power fault suspected flowchart 162
 - login failure 205
 - printer faults flowchart 198
 - reseating a card 167
 - system console fault suspected flowchart 176
 - system start-up problem 182
 - diagnostic tools
 - error message 296
 - dial-up problem
 - diagnostic procedure flowchart 185
 - DID see Direct Inward Dialing (DID)
 - difficulty logging in
 - ccusr 205
 - maint 206
 - mlusr 207
 - Direct Inward Dialing (DID) 469
 - directory number (DN) 469
 - Directory Number Identification Service (DNIS) 469
 - disable filter command 125
 - disable link command 91
 - disable message statistics collection command 122
 - disable monitor command 133
 - disable recording command 129
 - disable traffic command 136
 - disabling
 - Ethernet LAN support 458
 - printers 66
 - traffic 39
 - disk
 - read/write fault 204
 - disk slicing table 405
 - disk/tape unit
 - location in Application Module 8
 - read/write fault 204
 - diskuse command 47
 - display link command 100
 - display linkctl command 94
 - display messages 258
 - displaying
 - link statistics 114
 - message statistics 121, 123
 - port characteristics 57
 - software package version 153
 - status of configured printers 65
 - DN see directory number (DN)
 - DNIS see Directory Number Identification Service (DNIS)
 - DTMF see Dual Tone Multi-Frequency (DTMF)
 - Dual Tone Multi-Frequency (DTMF) 470
- ## E
- editvoice command 47
 - enable filter command 125
 - enable link command 91
 - enable message statistics collection command 121
 - enable monitor command 132

- enable record command 129
- enable traffic command 135
- enabling
 - Ethernet LAN support 458
 - printers 65
 - traffic 39
- Enhanced Serial Data Interface (ESDI) 470
- environment prompt
 - IPE Module 379
 - MVME147 card 374
 - MVME167 card 378
- error message
 - Application Module 235
 - diagnostic tools 296
 - internal 264
 - IPE Module 235
 - link 289
 - mlusr 291
 - mlusr command failure 289
- ESDI *see* Enhanced Serial Data Interface (ESDI)
- exit command 48, 150
- express powerdown 59

F

- failure
 - Meridian Link application registration 225
 - Meridian Link call processing 228
 - Meridian Link messages 231
 - mlusr command 289
- fault
 - card 165
 - diagnosing 155
 - disk/tape unit 204
 - power (Application Module) 156
 - power (IPE Module) 162
 - printer 198
 - system console 176
- file
 - log 82
 - recording 128

- restoring 454
 - viewing commands 148
- filedelete command 49
- fileverif command 50
- filter commands 124
- flowchart
 - card fault procedure (Application Module) 168
 - card fault procedure (IPE Module) 174
 - dial-up problem diagnostic procedure 185
 - power fault diagnostic procedure (Application Module) 156
 - power fault diagnostic procedure (IPE Module) 162
 - printer fault diagnosis procedure 198
 - system console fault diagnostic procedure 176
 - terminal problem diagnostic procedure 188
- format command 86
- function
 - ccusr 15
 - maint 15
 - mlusr 15
 - trmcnfg 16

G

- get associations command 118
- get directory numbers command 119
- get filter status command 126
- get links command 92
- get message statistics command 123
- get monitor status command 134
- get record command 130
- get resource command 120
- get traffic command 136

H

- hard disk/read/write fault 204
- hardware
 - Application Module components 4
 - IPE Module components 11
 - power up 368
 - powerdown 368

replacement procedure 369
 help command 51, 150
 host link configuration parameters
 link failure 217

I

I/O
 connectors 13
 indicator
 SBC card 11
 initializing the system
 tape 392
 inserting tape into tape drive 24, 28, 32
 install command 52
 installing
 BOS (IPE Module) 410
 BOS (MVME147 card) 393
 BOS (MVME167 card) 410
 BOS tape in tape drive 398
 Intelligent Peripheral Equipment (IPE) Module *see* IPE Module
 Interactive Voice Response (IVR) 229, 470
 internal error message 264
 IPE Module 470
 components 11
 definition 470
 error messages 235
 overview 1
 removing 385
 replacing 385
 IPE Module utilities
 ccrusr 15
 maint 15
 mlusr 15
 trmcnfg 16
 IVR *see* Interactive Voice Response (IVR)

J

jumper setting
 MVME333-2 XCC card 380

MVME705B card 390

K

keycode
 example of use 443

L

langconfig command 55
 LED
 ACC card 6
 SBC card (Application Module) 4
 SBC card (IPE Module) 11
 XCC card 5
 link
 changing control file 95
 changing parameters 102
 disabling 91
 displaying all control files 94
 displaying control file 98
 displaying information 92
 displaying parameters 100
 displaying statistics 114
 displaying status 92
 enabling 91
 reconfiguring parameters 113
 saving control file 99
 saving parameters 112
 link (link 1) not established 215, 223
 link 0 (LAPB)
 configuration 100
 statistics 114
 link 0 not established
 diagnosing 208
 link 1 (X.25)
 configuration 100, 101
 statistics 116
 link 1 not established
 diagnosing 215, 223
 link 2 not established
 diagnosing 224

- link 2 statistics 115
- link configuration commands 94
- link control commands 91
- link error message
 - mlusr command failure 289
- link failure
 - AM link (link 0) not established 208
 - diagnosing faults 208
 - host link (link 1) not established 215, 223
 - host link configuration parameters 217
 - MML (link 2) not established 224
- link maintenance command 85
 - association services commands 118
 - change link 102
 - change linkctl 95
 - clear filter messages 126
 - clear message for monitoring 133
 - clear messages for statistics 122
 - clear record 130
 - continuity test 143
 - disable filter 125
 - disable link 91
 - disable message statistics collection 122
 - disable monitor 133
 - disable recording 129
 - disable traffic 136
 - display link 100
 - display linkctl 94
 - enable filter 125
 - enable link 91
 - enable message statistics collection 121
 - enable monitor 132
 - enable record 129
 - enable traffic 135
 - exit 150
 - file viewing commands 148
 - filter commands description 124
 - format 86
 - get associations 118
 - get directory numbers 119
 - get filter status 126
 - get links 92
 - get message statistics 123
 - get monitor status 134
 - get record 130
 - get resource 120
 - get traffic 136
 - help 150
 - link configuration commands 94
 - link control 91
 - link statistics 114
 - link status commands 92
 - link testing commands 143
 - link tracing commands 139
 - loopback test 144
 - Meridian Link messages 117
 - message statistics commands 121
 - miscellaneous commands 150
 - monitor commands 131
 - quit 150
 - read link 113
 - read linkctl 98
 - record commands description 127
 - save link 112
 - save linkctl 99
 - set filter 124
 - set monitor 131
 - set record 128
 - status link 92
 - summary 87
 - trace link 139
 - trace main 139
 - traffic commands 135
 - untrace link 139
 - untrace main 139
 - using 86
 - version 153
 - view 148
 - viewlog 149
- link parameters
 - changing 102
 - reconfiguring 113

- summary 105
- link statistics command 114
- link status commands 92
- link testing commands 143
- link tracing commands 139

- listing
 - configured printers 65
 - printer job 66
- loading
 - application tape onto hard disk 439
 - BOS (IPE Module) 410
 - BOS (MVME147 card) 393
 - BOS (MVME167 card) 410
- location
 - Application Module components 8
 - MVME705B transition card jumpers 391
 - MVME712A card 387
 - MVME712AM card 388
 - MVME712M card 389
- logging in 14
- logging out 14
- login
 - diagnosing failure 205
 - difficulty logging in as ccrusr 205
 - difficulty logging in as maint 206
 - difficulty logging in as mlusr 207
 - maint 15
 - prompt 14
- login failure
 - ccrusr 205
 - diagnosing faults 205
 - maint 206
 - mlusr 207
- loopback test command 144

M

- maint
 - description 15
 - login 15
 - login failure 206
 - messages 241
- maint message
 - summary 241
 - SysLog file 278
- maintenance 16

- menu
 - start-up interrupt 372, 394
- Meridian 1 utilities
 - overview 2
- Meridian Link
 - diagnosing faults 231
 - message names 117
 - message types 117
 - overview 2
 - specifying message types 117
- Meridian Link application malfunction
 - application registration fails 225
- Meridian Link messages 117
- Meridian Link Module
 - removing 383
 - replacing 384
- Meridian Link Module debugging tool
 - application failure 231
- message
 - application 237
 - Application Module and IPE Module errors 235
 - bad event 284
 - CCR log file 304
 - clearing statistics 122
 - counting 135
 - diagnostic tools error 296
 - display 258
 - displaying statistics 123
 - filtering 124
 - internal error 264
 - link error 289
 - maint 241
 - Meridian Link 117
 - mlusr error 291
 - monitoring 131
 - name 117
 - other 258
 - power down 364, 366
 - recording 127
 - shut down 365
 - specifying type 117
 - statistics 121
 - SysLog 258
 - SysLog file 264, 285
 - system and UNIX 236
 - system console 236
 - system restart 371, 393
 - system watchdog 262
 - type 117
 - viewing CCR log file 301
- message statistics commands 121
- midnight command 36
- miscellaneous commands 150
- mlexit command 56
- mlstart command 56
- mlusr
 - Application Module command 56
 - command failure 289
 - description 15
 - error message 291
 - login 15
 - login failure 207
 - removing a stale association 298
- mlusr message
 - summary 256
- MML (link 2) not established
 - diagnosing 224
- modem testing 186
- Module Power Distribution Unit (MPDU) *see* MPDU
- monitor commands 131
- MPDU 470
 - circuit breaker 10
- MSDL card *see* Multi-use Serial Data Link (MSDL) card
- Multi-use Serial Data Link (MSDL) card 471
- MVME147 card
 - configuring 371
 - LEDs and switches 4
- MVME167 card
 - configuring 376
- MVME167 SBC card
 - LEDs and switches 5

MVME333-2 XCC card
 jumper settings 380
 replacing 380
 MVME705B card
 jumper settings and cable connections 390
 overview 7
 reconfiguring 390
 replacing 390
 serial port configuration 391
 MVME712 card
 replacing 386
 MVME712A card
 configuration 387
 overview 6
 MVME712AM card
 configuration 388
 overview 6
 MVME712M card
 configuration 389
 overview 6

N

Northern Telecom Publication (NTP) 471
 NT6D51 transition card
 replacing 382
 NT6D51AA card overview 7
 NTP see Northern Telecom Publication (NTP)

O

OA&M see Operations, Administration and
 Maintenance (OA&M)
 Operations, Administration and Maintenance (OA&M)
 471
 overlay 471

P

parameter
 changing 102
 configuration 217

 link 105
 reconfiguring 113
 saving 112
 PBX 468, 469
 port characteristics
 changing 58
 displaying 57
 portconfig
 Application Module command 57
 changing port characteristics 58
 displaying port characteristics 57
 position ID 341
 power
 diagnosing fault (Application Module) 156
 diagnosing fault (IPE Module) 162
 power fault suspected (Application Module)
 diagnostic procedure flowchart 156
 power fault suspected (IPE Module)
 diagnostic procedure flowchart 162
 power sense card 9
 power supply 8
 power up
 hardware 368
 powerdown
 Application Module command 59
 hardware 368
 procedure 364
 software 364
 with time delay 60
 powerdown notification message 364, 366
 printconfig
 adding a printer 64
 Application Module command 63
 delete printer job 66
 deleting a printer 64
 disabling
 printers 66
 enabling
 printers 65
 list printer job 66
 listing configured printers 65

- status of configured printers 65
- printer
 - adding 64
 - deleting 64
 - disabling 66
 - displaying status 65
 - enabling 65
 - listing 65
 - listing jobs 66
- printer fault
 - diagnostic procedure flowchart 198
- problem
 - diagnosing 155
 - dial-up 185
 - start-up 182
- procedure
 - backing up configuration files and data files 452
 - configuring Application Module MVME147 card 371
 - configuring Application Module MVME167 card or IPE Module 376
 - enabling/disabling Ethernet LAN support 458
 - hardware replacement 369
 - loading application tape onto hard disk 439
 - loading operating system 410
 - loading operating system (MVME147 card) 393
 - power up 368
 - powerdown 368
 - powerdown and restart 364
 - rebooting and setup 429
 - recovery/replacement 363
 - removing the Application Module 383
 - removing the IPE Module 385
 - replacing Application Module disk/tape unit 369
 - replacing Application Module MVME147/67 SBC card 370
 - replacing Application Module power supply 369
 - replacing MVME333-2 XCC card 380
 - replacing the Application Module 384
 - replacing the IPE Module 385
 - replacing the MVME712 card 386

- replacing the NT6D51 transition card 382
- replacing/reconfiguring the MVME705B card 390
- restoring backed-up files 454
- SBC restart 366
- profile 14, 456, 457

Q

- QPC513 470, 471
- quick reference
 - fault isolation 155
- quit command 67, 150

R

- read link command 113
- read linkctl command 98
- read/write fault
 - hard disk drive 204
 - tape drive 204
- rebooting system 429
- reconfiguring
 - MVME705B card 390
- record commands 127
- recording file
 - example 128
- recovery and replacement procedures 363
- reinstallation
 - software 392
- remote maintenance 6
- removing
 - IPE Module 385
 - Meridian Link Module 383
 - stale mlusr association 298
- replacing
 - Application Module disk/tape unit 369
 - Application Module MVME147/167 SBC card 370
 - Application Module power supply 369
 - IPE Module 385
 - Meridian Link Module 384
 - MVME333-2 XCC card 380
 - MVME705B card 390

- MVME712 card 386
- NT6D51 transition card 382
- reseating a card
 - procedure 167
- resetmodem command 67
- restart
 - Application Module command 68
 - procedure 364
- restoring files from backup 454
- restoring files selectively 73
- rootpasswd command 69
- route 471
- rstdata command 70
- rstfiles command 73

S

- save link command 112
- save linkctl command 99
- SBC card
 - Application Module 4
 - configuring MVME147 371
 - configuring MVME167 376
 - indicators (LEDs) 11
 - SBC card 4
 - IPE Module 11
 - location in Application Module 8
 - restart procedure 366
 - switches (IPE Module) 12
- script 14, 74, 469
 - definition 471
 - state 74
 - statistics 37, 38, 41
 - statistics output 41
- scriptinfo command 74
- SCSI 5
- SDI port 45
- set filter command 124
- set monitor command 131
- set record command 128
- setting up
 - after rebooting 429
 - showid command 75
 - shutdown message 365
 - Single Board Computer (SBC) card 4, 11
 - software
 - powerdown 364
 - reinstallation 392
 - specifying message type 117
 - SSID see Standalone System Interactive Diagnostics (SSID)
 - stale association 298
 - Standalone System Interactive Diagnostics (SSID) 472
 - start-up interrupt menu 372, 394
 - start-up problem
 - diagnostic procedure 182
 - startNSE command 76
 - statistics
 - link 0 (LAPB) 114
 - link 1 (X.25) 116
 - link 2 115
 - message 121
 - status link command 92
 - status of configured printers 65
 - stopNSE command 77
 - summary
 - application messages 237
 - application messages in SysLog file 265
 - Application Module Commands 18
 - link maintenance commands 87
 - link parameters 105
 - maint messages 241
 - mlusr messages 256
 - SysLog file maint messages 278
 - SysLog messages 258
 - SysLog messages in SysLog file 285
 - system watchdog messages 262
 - system watchdog messages in SysLog file 286
- switch
 - SBC card (Application Module) 4
 - SBC card (IPE Module) 12
- SysLog file

- application messages 265
- bad-event message 284
- maint messages 278
- other messages 285
- system and UNIX messages 264
- system watchdog 286

- SysLog file maint message
 - summary 278
- SysLog message
 - summary 258
 - SysLog file summary 285
- system
 - messages 236
 - SysLog file message 264
- system console
 - diagnosing fault 176
 - messages 236
- system console fault suspected
 - diagnostic procedure flowchart 176
- system restart messages 371, 393
- system setup 429
- system start-up problem
 - diagnostic procedure 182
- system watchdog
 - message summary 262
 - messages 262
 - SysLog file 286

T

- tape
 - initializing the system 392
 - inserting 24, 28, 32
 - installing BOS tape in tape drive 398
 - read/write fault 204
 - write-protection disabled 23, 27, 31
- tape/disk drive unit fault
 - read/write fault 204
- tapeinfo command 78
- terminal number (TN) 472
- terminal problem
 - diagnostic procedure flowchart 188
- testing
 - for applications 187
 - modem 186
- testing links 143
- TN see terminal number (TN)

- trace examples 140
- trace link command 139
- trace main command 139
- traffic commands 135
- transition card
 - location in Application Module 9
 - replacing 386
- trmcnfg
 - description 16
 - login 16
- troubleshooting 155

U

- UNIX
 - messages 236
 - SysLog file message 264
- untrace link command 139
- untrace main command 139
- USM 233

V

- Value Added Server Identification (VAS ID) 212
- variable 472
- Versa Module Eurocard (VME) 472
- version command 79, 153
- view command 82, 148
- viewing
 - a file 148
 - file 83
 - traffic history 39
 - traffic report configuration 40
- viewing a file
 - available commands 149
- viewlog command 84, 149
- Voice Response Unit (VRU) 472
- VRU see Voice Response Unit (VRU)

W

- warning notice 156
- watchdog
 - messages 262
- write-enabled tab
 - cassette tape 23, 27, 31

X

- X.25 Communication Controller (XCC) card
 - LED 5
- XCC card
 - jumper settings 380
 - LED 5
 - location in Application Module 8
 - replacing 380